

**2018 Entegra 45B Titanium Comprehensive Service Done by Lazy Days RV Villages FL 12/13/22**

RV MAINTENANCE SERVICES	SILVER	DIAMOND	GOLD	PLATINUM	TITANIUM
Inspect Fan Belts	✓	✓	✓	✓	✓
Inspect Radiator Heater Hoses	✓	✓	✓	✓	✓
Inspect Air Filter (gas only)	✓	✓	✓	✓	✓
Inspect Air Filter Gauge (diesel only)	✓		✓	✓	✓
Inspect Window Seals Sealant	✓	✓	✓	✓	✓
Inspect Polarity Voltage	✓	✓	✓	✓	✓
Inspect Operation of Exterior Lights	✓	✓	✓	✓	✓
Inspect Directional Signals	✓	✓	✓	✓	✓
Inspect Dump Valve	✓	✓	✓	✓	✓
Service House Chassis Batteries	✓	✓	✓	✓	✓
Check House Converter Charging System	✓	✓	✓	✓	✓
Check Top Off Fluid Levels (excludes DEF tank)	✓	✓	✓	✓	✓
Lubricate Entry Step	✓	✓	✓	✓	✓
Replace Engine Oil Oil Filter (up to 8 quarts gas — up to 24 quarts diesel)	✓		✓	✓	✓
Replace Generator Oil Oil Filter	✓		✓	✓	✓
Clean Lubricate Slack Adjusters (diesel only)	✓		✓	✓	✓

**DIESEL**

**\$4,759.99**

RV MAINTENANCE SERVICES	SILVER	DIAMOND	GOLD	PLATINUM	TITANIUM
Visual Inspection of Dates Condition of Tires	✓	✓	✓	✓	✓
Adjust Tire Pressures (Note: tire pressures will be adjusted to the manufacturer's placard)	✓	✓	✓	✓	✓
Service Water Heater		✓	✓	✓	✓
Service Refrigerator		✓	✓	✓	✓
Service Stove		✓	✓	✓	✓
Service Furnace		✓	✓	✓	✓
Clean or Replace AC Filters		✓	✓	✓	✓
Service Aqua-Hot® (diesel only)		✓	✓	✓	✓
Replace Generator Air Filter			✓	✓	✓
Replace Generator Fuel Filter			✓	✓	✓
Replace Engine Air Filter				✓	✓
Replace Engine Fuel Filter			✓	✓	✓
Replace Water Separator (diesel only)			✓	✓	✓
Test Water Pump City Water		✓		✓	✓
Clean Sanitize Gray Black Tanks				✓	✓
Fill Fresh Water				✓	✓
Clean Flush Outside Radiator Coils				✓	✓
Service Slides Jacks		✓		✓	✓

**DIESEL**

**\$4,759.99**

RV MAINTENANCE SERVICES	SILVER	DIAMOND	GOLD	PLATINUM	TITANIUM
Replace Wiper Blades (Note: parts price will vary by model)				✓	✓
Clean Washer Nozzles		✓		✓	✓
Replace Hydraulic Filters (diesel only)				✓	✓
Service Air Tank System				✓	✓
Service Air Dryer				✓	✓
Complete Lubrication of Chassis		✓		✓	✓
Check Inspect Engine Support Fasteners					✓
Check Inspect Alternator, Battery Starter					✓
Check Inspect Transmission Hose Routing for Chaffing Leaks					✓
Check Inspect Suspension					✓
Check Inspect Suspension Height Control Valve					✓
Check Inspect Suspension U-bolt Torque					✓
Check Inspect Oil Level of Oil-Filled Hubs					✓
Check Inspect Axle Seals for Leaks					✓
Check Inspect Axle Breather					✓
Check Inspect Brake System Valves					✓

RV MAINTENANCE SERVICES	SILVER	DIAMOND	GOLD	PLATINUM	TITANIUM
Check Inspect Bendix Hydromax Brake System (front engine only)					✓
Check Inspect Air Brakes					✓
Check Inspect Hydraulic Disc or Air Brake Lines					✓
Check Inspect Hydraulic Disc Brake Lining For Wear (front engine only)					✓
Check Inspect Fuel Tank Mounts Fuel Lines					✓
Check Inspect Exhaust System					✓
Check Inspect AC Components					✓
Lubricate Throttle Pedal Pivot Pin					✓
Lubricate ZF IFS (independent front suspension)					✓
Lubricate Camshaft Bracket Bushing					✓
Lubricate Foot Brake Valve Actuator					✓
Lubricate Meritor Roll Pin					✓
Lubricate Drag Link					✓
Lubricate Bosch Brake Caliper Slide Pin					✓
Inspect Service Pacbrake					✓
Charge Air Cooler Inspection Cleaning					✓

SERVICES	SILVER	DIAMOND	GOLD	PLATINUM	TITANIUM
Change Transmission Fluid Filter (if required by Allison)					✓
Remove, Clean, Repack Adjust Wheel Bearings					✓
Change Axle Lubricant (Freightliner axle Only)					✓
Check Clean Ground Cables					✓
<b>DIESEL</b>					<b>\$4,759.99*</b>

Cornerstone

## K3 & K4 chassis lubrication points

<u>Lubrication point #</u>	<u>Lubrication point description</u>	<u>Notes</u>
1	Upper steering shaft, upper U-joint	
2	Upper steering shaft, slip	
3	Upper steering shaft, lower U-joint	
4	Lower steering shaft, upper U-joint	
5	Lower steering shaft, slip	
6	Lower steering shaft, lower U-joint	
7	Steering gear, master, output shaft	
8	Steering gear, slave, output shaft	
9	Front axle, LH upper king pin	
10	Front axle, LH lower king pin	
11	Front axle, LH upper carrier bearing	
12	Front axle, LH lower carrier bearing	
13	Front axle, LH tie rod @ steer arm	
14	Front axle, LH tie rod @ relay rod	
15	Front axle, RH upper king pin	
16	Front axle, RH lower king pin	
17	Front axle, RH upper carrier bearing	
18	Front axle, RH lower carrier bearing	
19	Front axle, RH tie rod @ steer arm	
20	Front axle, RH tie rod @ relay rod	
21	Tag axle, LH upper king pin	<i>(Passive Steer Tag Axle only)</i>
22	Tag axle, LH lower king pin	<i>(Passive Steer Tag Axle only)</i>
23	Tag axle, LH tie rod @ steer arm	<i>(Passive Steer Tag Axle only)</i>
24	Tag axle, RH upper king pin	<i>(Passive Steer Tag Axle only)</i>
25	Tag axle, RH lower king pin	<i>(Passive Steer Tag Axle only)</i>
26	Tag axle, RH tie rod @ steer arm	<i>(Passive Steer Tag Axle only)</i>
27	Drive shaft, U-joint @ drive axle	
28	Drive shaft, slip	
29	Drive shaft, U-joint @ transmission	
30	Drive shaft, fan system, slip	

